

SUMMIT

SINCE 1977

MONTY





FEATURES

- Lounge chair
- Fluted back



MATERIALS

- Fully Upholstered



FABRIC & FINISHES

Any fabric of your choice (please refer to Fabric Category document)

MONTY

Monty is a beautiful statement lounge chair. With a unique silhouette encompassing stitched fluting, a ‘floating’ seat and fully upholstered from top to toe! With a strong design-led aesthetic, Monty is a relaxed lounge chair which can be upholstered in two tone fabrics to create impact or softly furnished to create calm.

TESTIMONIAL

“Our most huggable chair with built-in lumbar for supreme comfort”

Measurements

MONTY



DIMENSIONS

Overall Width – 575mm

Overall height – 920mm

Overall Depth - 710mm

Care & Maintenance

PLASTIC, PAINTED STEEL, POLISHED TIMBER

Please use a soft, damp, non-abrasive cloth for cleaning plastic parts. Subsequent gentle drying is recommended. For stain removal, we recommend using a mild commercially available cleaner. Never use abrasive cleaning agents such as powders or pastes, or aggressive all-purpose cleaners like alcohol, as these may damage the surface. We recommend that you avoid exposing your chair to the sun for any longer than is necessary.

COVER FABRIC

To care for cover fabrics, simply Hoover dust and lint regularly using an upholstery nozzle. Any fresh stains can typically be removed by wiping immediately with an absorbent, lint-free sponge or cloth. Start from the outer edge of the stain and work inwards to avoid creating a halo effect, using normal household distilled water to prevent limescale residue.

ALUMINIUM

For quick removal of contaminants on polished high-shine, matte chrome and aluminium surfaces, apply a glass cleaner with a clean, soft cloth and subsequently wipe the surface dry with a soft cloth. Always clean metal surfaces gently and without scrubbing so that the surface is not scratched. Never use cleaners containing granular substances, acetic acid or citric acid.

To minimise the risk of damage please take some simple precautions:

Avoid exposure to excessive heat from a fire, radiator or local high temperature light sources.

Before using any cleaning product, you should test it on an inconspicuous spot. Please follow the cleaning product manufacturer's instructions and contact a professional cleaning company in case of stubborn dirt or stains.

Periodically check and tighten hardware as necessary. Any lost bumpers or feet should be replaced as soon as possible to avoid damage to the furniture or the floor surface.

Warranty

All of our chairs come with a 5 year structural guarantee, excluding fair wear and tear, and damage or failure caused by misuse. The guarantee applies for use up to 8 hours a day by users up to 150kg. Manufacturer's warranty applies to all fabrics.

Summit 1977 reserves the right to refuse replacement or repair if we feel that the product has been abused or has been accidentally damaged by another party. Summit 1977 also reserves the right to attempt to repair any damaged or faulty products

before a decision is made to replace them. In this case, we shall not be liable for any loss occurred by the distributor or customer during this period. Summit 1977 will not be liable whatsoever for any consequential damage, loss or other expenses whether arising out of contact, negligence or otherwise. Any alterations to our products in any manner will automatically nullify any guarantees ordered by Summit 1977.

Talk to one of our *experts* to
find the furniture that fits
your *inspiring* space.

